

IF SELF TAPPING SCREWS  
PENETRATE WEATHER  
BARRIER, THESE LOCATIONS  
MUST BE SEALED

#10 X 3/8" SELF TAPPING  
SCREWS MAY BE USED WITH  
EXTERIOR INSULATED WALLS

AH-203 EXTRUSION FULL LENGTH  
BETWEEN BASE EXTRUSIONS  
(ATTACH T-CLIPS PRIOR TO  
INSTALLING VERTICAL PANEL)  
-OR-  
USE AH-205 J-SILL FULL LENGTH  
BETWEEN BASE EXTRUSIONS

#10 X 3/4" SELF  
DRILLING SCREW  
(1) PER CLIP

OUTLINE OF  
AH-202  
BASE BELOW

SHIM AS REQ'D

1-5/8"

AH-401 FRAME  
EXTRUSION

AH-107 T-CLIP

1/2"  
MIN.

4 MM VITRABOND  
FR CORE MCM

AH-203  
HEAD  
EXTRUSION

WEATHER BARRIER  
AS REQUIRED.  
DESIGN BY  
ARCHITECT

CONT. INSULATION  
W/ VERT. SUBGIRTS, TYP.

Sheet

15

Drawn By  
JSJ

Date Drawn  
10/03/18

Revisions

No. Date  
No. Date

Project Number

DWG-01

Project

ARROWHEAD LEAN SOFFIT TO WALL DETAIL  
GRID INSTALLATION

© Copyright Fairview Architectural LLC - Patented and/or Patent Pending

**FAIRVIEW**  
ARCHITECTURAL  
**arrowhead**  
ARCHITECTURAL PANEL SYSTEMS

www.fairview-na.com